

Upgrade instructions:

1. The file does not need to be unzipped, but directly placed in the root directory of the SD card;
2. Insert the SD card into the machine and click Settings - General - Software version - Update from MicroSD Card start the upgrade.
3. In order to execute the update, please ensure that your unit's free memory space remaining is at least twice the size of the update's file size.
4. In order to execute the update, please ensure that your unit's battery power is greater than 30% remaining.
5. The update will take approximately 10 minutes. Once you begin the update, please do not operate the unit until the update has completed.

1. Soubor NEROZBALUJTE.

2. Aktualizační soubor je třeba umístit přímo do kořenového adresáře SD karty.
3. Vložte SD kartu do přístroje a kliknutím na Settings - General - Software version - Update from MicroSD Card spustíte aktualizaci.
4. Chcete-li provést aktualizaci, zajistěte, aby zbývající volné místo v paměti vaší jednotky bylo alespoň dvakrát větší než velikost souboru aktualizace.
5. Pro správný průběh aktualizace zajistěte, aby zbývající kapacita baterie vaší jednotky byla vyšší než 30 %.
6. Aktualizace bude trvat přibližně 10 minut. Jakmile zahájíte aktualizaci, nepracujte s jednotkou, dokud není aktualizace dokončena.